



# Accessory and Installation for Flex-LED Rope (JE-00XY-NF)

## 1. Accessories



FN101— 110 AC input Power Converter, drive  
1000 feet/pc



FN102— Connection pin from Power converter  
to flex tube



FN103— Connection pin from tube to tube



FN104— Up L connector from tube to tube



FN105—Outside L connection from tube to tube



FN106— Inside L connector from tube to tube



## Accessory and Installation for Flex-LED Rope (JE-00XY-NF)

---



FN107— Up T connector from tube to tube



FN108— End cap



FN109/FN110— 2 FT/ 6 FT Extension Connector



FN111— Shrink tube for connected protection



FN112— 2 inch C aluminum mount



FN113— 36 inch C aluminum mount



# Accessory and Installation for Flex-LED Rope (JE-00XY-NF)

## 2. Installation



Figure 1: Connect Power converter to tube



Figure 2: Connect tube to tube



Figure 3: Connect tube to tube on stand up way  
Via L connect



Figure 4: Connect tube to tube via extension  
connector



## Accessory and Installation for Flex-LED Rope (JE-00XY-NF)




Figure 5: Connect tube to tube on outside way  
Via L connector



Figure 6: Connect tube to tube on inside way  
Via L connector




Figure 7: Connect tube to tube via T connector




Figure 8: Put the end cap on the end



Figure 9: Shrink the tube by heater for each  
Connected portion




Figure 10: Push the tube into aluminum mount